



Donaldson®
FILTRATION SOLUTIONS
AFS | LE BOZEC | WESTERN FILTER

17891 Chesterfield Airport Road
Chesterfield, MO 63005

**FAA APPROVED
ROTORCRAFT FLIGHT MANUAL SUPPLEMENT
TO THE**

**BELL HELICOPTER TEXTRON CANADA (BHTC) LIMITED
BELL MODEL 407
ROTORCRAFT FLIGHT MANUAL**

**FOR THE
INLET BARRIER FILTER SYSTEM
INSTALLATION**

Aircraft S/N _____ Aircraft Reg. No. _____

This supplement must be attached to applicable FAA Approved Rotorcraft Flight Manual when the rotorcraft is modified by the installation of the AFS Inlet Barrier Filter (IBF) System in accordance with STC No. SR09368RC.

The information contained herein supplements or supersedes the basic manual only in those areas listed herein. For limitations, procedures, and performance information not contained in this supplement, consult the basic Rotorcraft Flight Manual.

FAA Approved


for: Steve Lardinois
Manager, Systems and Flight Test, ACE-117C
Federal Aviation Administration
Des Plaines, IL 60018

Approval Date: **FEB 12 2015**

LOG OF PAGES

Revision No.	Page		Description	FAA Approved
	No.	Date		
IR		12-10-03	Initial Release	Carl F. Mittag
A	Title i LOP ii Contents 1 thru 9 1 3 4 5 thru 9 5 7 9	9-13-04	-Changed logo & corrected STC no. -Revision A changes. -Changed page numbers for Sections 3 thru 5 & Appendix. -Total pages changed from 8 to 9. -Removed all performance chart specifics & added Section 4 reference. -Added reference to Figure 2-1 & NOTE for FMA use with snow doors. -New page 4 to add Figure 2-1. -Changed page numbers from "4 thru 8" to "5 thru 9" due to added page. -Modified NOTE under FILTER FAULT CONDITION. -Changed to indicate use of PURGE ON instead of PURGE OFF charts when IBF is installed except for PAC; added NOTE for PAC with IBF. -Changed to reference Section 4 for performance charts with IBF installed; added NOTE referencing notes added to Sections 2 & 3.	Carl F. Mittag
B	1-11 3 4 9	3-21-07	-Renumbered Pages -Added detail to description -Added Instrument Markings and Placards -Changed from using "Purge On" charts to "Purge Off" charts	Superseded
C	ii 1 5 9 11	6-19-07	-Corrected page numbers -Replaced Carl Mittag with Lance Gant -Added "PREFLIGHT CHECK" -Corrected typographical error -Added page number	Lance T. Gant

LOG OF PAGES (CONT'D)

Revision No.	Page		Description	FAA Approved
	No.	Date		
D	4	5-14-10	-Clarified "circuit breaker" wording. -Updated cockpit/indicator switch figures and expanded description. -Added reference to Bell RFMS BHT-407-FMS-8 -Changed to allow use of basic inlet or EAPS performance charts with IBF installed if PAC completed successfully in respective configuration. Also added allowance of Operations With Improved Hover Performance with IBF installed and strict compliance with FMS BHT-407-FMS-8. -Added Improved Hover Performance STC configuration.	Lance T. Gant Jun 23, 2010
	5			
	10-11			
	13			
E	Cover page	30 Jan 15	Updated Logo & address Removed specific Flight Manual number	 FEB 12 2015

NOTE

Revised text is indicated by a black vertical line in the right border.

TABLE OF CONTENTS

SECTION	TITLE	PAGE
	General Information	4
1	Limitations	5
2	Normal Procedures	6
3	Emergency/Malfunction Procedures	8
4	Performance	10
5	Weight and Balance	12
Appendix A	Optional Equipment Supplements	13

GENERAL INFORMATION

The Inlet Barrier Filter (IBF) STC kit (106000-101) consists of a removable barrier filter assembly, integral seals, mounting adapter frame, differential pressure switch, filter maintenance aid, inlet plenum floor with bypass door/actuator assembly, two floor closeout angles, a cockpit dual indicator/actuator switch, and an engine wash nozzle/supply tube assembly. The kit also includes all unique installation hardware and wiring. An alternate kit (106000-103) includes the basic IBF installation as described above and adds an optional quick "access door".

The IBF system provides a means of monitoring the condition of the filter both in-flight and on the ground, and a bypass capability should flow through the filter become restricted. In-flight, the differential pressure switch continuously measures the drop in pressure across the filter, and triggers the cockpit indicator/switch cautioning the pilot any time the differential pressure across the filter reaches or exceeds a preset value.

Installation of the IBF STC requires that the engine bleed air or scavenge air used by the Engine Air Particle Separator (if installed), be capped, the "PART SEP" purge air toggle switch be removed, and the 5 amp circuit breaker be replaced by a 3 amp circuit breaker.

The electromechanically actuated bypass door permits unfiltered air to enter the engine inlet chamber, should the filter media become obstructed, and can be opened or closed as required by pressing the cockpit indicator/switch located in the instrument panel. The bypass system also includes a three amp circuit breaker located in the overhead panel, installation hardware and wiring.

Operation of the aircraft with the IBF system installed requires use of the same performance information and charts as required in the Rotorcraft Flight Manual (RFM), RFM Supplement BHT-407-FMS-3 for the Bell Engine Air Particle Separator kit, and RFM Supplement BHT-407-FMS-8 for the Improved Hover Performance With Above Minimum Specification Power (Supplemental Type Certificate number SR095531RC-D) for all operations as defined in Section 4 of this supplement. Therefore no new performance charts are required for installation and use of the IBF system.

Section 1

LIMITATIONS

INSTRUMENT MARKINGS AND PLACARDS

IBF

Placard is located near the 3 amp circuit breaker and the cockpit indicator/switch.

differential is above a preset value.

The "BYPASS" segment of the switch illuminates when the bypass door is open.

NOTE

The "FILTER" segment should be extinguished when the "BYPASS" segment is illuminated.



Amber



Amber

The indicator/switch is used to open/close the filter bypass door, to alert the pilot when the filter becomes restricted, and to alert the pilot when the bypass door is open (both conditions shown).

The switch is segmented to indicate two conditions:

The "FILTER" segment of the switch illuminates when the pressure

Section 2

NORMAL PROCEDURES

PREFLIGHT CHECK

FUSELAGE – CENTER RIGHT SIDE

1. Check IBF Filter Maintenance Aid to determine condition of the filter. When indicator enters RED zone (see Figure 2-1 of this FMS), service filter per IBF Instructions for Continued Airworthiness, AFS-BH407-IBF-KIT-ICA.

NOTE

During flight operations with the engine air inlet snow deflector kit installed, the Filter Maintenance Aid (FMA) will not provide accurate readings and therefore should not be used. Upon removal of the snow doors, reset the FMA prior to next flight.

2. Perform a visual check that the bypass door is in the closed position.

BEFORE FLIGHT WHEN OPERATING IN SNOW CONDITIONS

1. Thoroughly check cabin roof, transmission cowling, deflector baffles and engine air intake areas. All areas checked shall be clean and free of accumulated snow, slush, and ice before each flight.
2. Check engine air plenum chamber through plexiglass windows on each side of inlet cowling for snow, slush, or ice, paying particular attention to the firewall, the rear face of Inlet Barrier Filter assembly, and the IBF bypass door and surrounding floor area. Ensure all are thoroughly clear of snow, slush, or ice before each flight.




Figure 2-1. FILTER MAINTENANCE AID – (ABOVE) “YELLOW Indicator” position relative to SAFE OPERATING ZONE (“GREEN Zone”) or SERVICE FILTER (“RED Zone”) markings defines current filter condition and pushing “YELLOW RESET Button” resets indicator. (BELOW) FMA unit is mounted to bottom of IBF floor assembly and is accessed through RH access door on air inlet cowl assembly.



Section 3

EMERGENCY/MALFUNCTION PROCEDURES

Caution lights (amber)

PANEL WORDING	FAULT CONDITION	CORRECTIVE ACTION
FILTER (amber)	Illumination of IBF FILTER light indicates that the normal operating differential pressure across the engine air inlet filter has been exceeded. NOTE As the filter assembly becomes contaminated or during flight with the snow deflector kit installed, certain flight conditions may cause the indicator to flicker intermittently. Corrective action should be taken only when the indicator illumination is continuous.	Monitor MGT for any significant rise, i.e. > 20°C. Monitor engine conditions for any indications of engine degradation or compressor stall, i.e. MGT fluctuations, and decreasing or fluctuating N1 rpm. If rise in MGT or engine performance is unacceptable: • Open bypass door by pressing illuminated FILTER button. • BYPASS light should illuminate and FILTER light should go out indicating the bypass door is open and the pressure differential is back within the normal range. Service filter prior to next flight. NOTE If FILTER light illuminates during take-off, recommend servicing the filter before continuing flight.

CAUTION

TO PREVENT COMPRESSOR EROSION AVOID OPERATION IN A DIRTY OR DUSTY ENVIRONMENT WITH THE FILTER BYPASS DOOR OPEN.

PANEL WORDING	FAULT CONDITION	CORRECTIVE ACTION
"BYPASS"	The bypass door is open and the filter is being bypassed with unfiltered air entering the engine.	If the flight or landing environment has significant dirt or debris, it is recommended that the bypass door be closed, provided no rotorcraft or engine limits will be exceeded. With the bypass closed, the "BYPASS" segment will extinguish and the "FILTER" segment will potentially re-appear under high engine power settings until the filter has been cleaned.
	Inadvertent encounters with icing.	Exit condition as soon as practical.

Section 4

PERFORMANCE

OPERATIONS WITH STANDARD BELL 407 CONFIGURATION

When the Inlet Barrier Filter (IBF) system STC is installed, use the basic inlet Power Assurance Check (PAC) chart (hover or level flight) contained in the basic RFM to determine engine health. If the PAC is satisfactory then basic performance can be obtained and the basic inlet performance data charts are applicable.

If the basic PAC is not satisfactory then published performance may not be achieved. If this is the case, either clean the IBF filter and recheck the engine health using the basic inlet PAC chart, or compare the recorded PAC values against the Engine Air Particle Separator (EAPS) chart located in the Particle Separator supplement (BHT-407-FMS-3).

If engine health is found to be satisfactory using the EAPS PAC chart, then the EAPS performance can be obtained and the EAPS performance data charts are applicable. If the engine health is not satisfactory, then clean the filter and conduct another PAC check, and compare the results to the basic inlet PAC chart or the EAPS PAC chart.

If the recorded PAC results after cleaning the filters are still not satisfactory, then contact maintenance for troubleshooting.

The frequency at which PAC's are conducted is up to the discretion of the operator based on the operating environment, (i.e. temperature, altitude, airborne contaminate) and the requirements of the Flight Manual.

OPERATIONS WITH IMPROVED HOVER PERFORMANCE STC CONFIGURATION (STC No. SR095531RC-D)

When operating with the Improved Hover Performance With Above Minimum Specification Power STC (Plus Power) installed, use of the procedures and data found in the FAA approved FMS are applicable (BHT-407-FMS-8).

NOTE

All requirements, as outlined in BHT-407-FMS-8 apply with the IBF installed and must be adhered to.

Use the basic inlet "Plus Power" PAC chart to determine engine health with the average of the 10 most recent PAC events.

If the basic inlet "Plus Power" PAC is satisfactory, then performance can be achieved using the appropriate performance charts in BHT-407-FMS-8.

If the basic inlet "Plus Power" PAC is not satisfactory (i.e. "Plus Power" margin is 2.0% or more lower than the average of the last 10 PAC values), then basic inlet "Plus Power" published performance may not be achieved. If this is the case, either clean the IBF filter and recheck the engine health using the basic inlet BHT-407-FMS-8 PAC chart, or compare the recorded PAC values against the EAPS PAC chart located in FMS BHT-407-FMS-8.

If the EAPS "Plus Power" PAC is satisfactory, performance can be achieved using the EAPS performance charts in FMS BHT-407-FMS-8.

If the EAPS "Plus Power" PAC is not satisfactory (i.e. "Plus Power" margin is 2.0% or more lower than the average of the last 10 PAC values), then EAPS "Plus Power" published performance may not be achieved. If this is the case, either clean the IBF filter and recheck the engine health using FMS BHT-407-FMS-8 PAC charts (basic inlet or EAPS), or compare PAC values using the standard Bell 407 configuration procedures as outlined in the "Operations With Standard Bell 407 Configuration" section of this manual listed above.

In order to use the Improved Hover Performance With Above Minimum

Specification Power performance charts, Power Assurance Checks must be conducted daily per the FMS.

NOTE

Use of performance charts presented in FMS BHT-407-FMS-8 is not authorized with Snow Deflector Kit (BHT-407-FMS-4) installed.

ALL CONFIGURATIONS



Helicopter performance is reduced as the IBF becomes contaminated with dirt, dust and debris. The pilot/operator is responsible to utilize the PAC procedure to determine if the engine can produce installed power.

If engine does not pass PAC, published performance cannot be achieved. Contact maintenance for appropriate trouble shooting procedures as outlined in applicable Instructions for Continued Airworthiness or Maintenance Manuals. Ensure that the IBF FILTER caution light is not illuminated during performance of the PAC.

Section 5

WEIGHT AND BALANCE

No change.

Appendix A

OPTIONAL EQUIPMENT SUPPLEMENTS

OPERATIONS WITH STANDARD BELL 407 CONFIGURATION

Operation of the aircraft with the IBF system installed requires use of the same performance information and / or charts as required in the Rotorcraft Flight Manual, and FMS BHT-407-FMS-3 for the Bell EAPS kit for all operations as defined in Section 4 of this supplement. Therefore no new performance charts are required.

NOTE

During flight operations with the engine air inlet snow deflector kit installed, see notes in Section 2 of this supplement relating to use of the IBF Filter Maintenance Aid, and in Section 3 of this supplement relating to intermittent FILTER light indications.

OPERATIONS WITH IMPROVED HOVER PERFORMANCE STC CONFIGURATION (STC No. SR095531RC-D)

Operation of the aircraft with the IBF system installed and in accordance with the performance charts contained in FMS BHT-407-FMS-8 requires that the Improved Hover Performance With Above Minimum

Specification Power STC be installed on the aircraft. In this configuration, operations shall be conducted in accordance with Section 4 of this supplement.

Performance charts are provided in BHT-407-FMS-8 for those operators who have the STC installed. Additional performance charts are contained in the basic RFM and FMS BHT-407-FMS-3.

NOTE

Use of performance charts presented in FMS BHT-407-FMS-8 is not authorized with Snow Deflector Kit (BHT-407-FMS-4) installed.