

GULFSTREAM AEROSPACE
GIV / G300 / G400 AIRPLANE FLIGHT MANUAL
SUPPLEMENT NO. GIV-2016-01

Gulfstream Aerospace Corporation Supplement No. GIV-2016-01
P.O. Box 2206
Savannah, Ga. 31402-2206

FAA APPROVED
AIRPLANE FLIGHT MANUAL
SUPPLEMENT FOR
GULFSTREAM MODELS GIV / G300 / G400

REGISTRATION NUMBER: _____

SERIAL NUMBER: _____

This Supplement must be attached to the FAA Approved GIV Airplane Flight Manual, dated 22 April 1987, G300 Airplane Flight Manual, dated 15 January 2003, and G400 Airplane Flight Manual, dated 18 November 2002, for GIV series (GIV / G300 / G400) airplanes serial number (S/N) 1000 and subsequent having sealant compound improperly applied to the APU enclosure.


The information contained herein supplements or supersedes the information of the basic Airplane Flight Manual. For Limitations, Normal Procedures, Abnormal Procedures, Emergency Procedures and Performance information not contained in this supplement, consult the basic Airplane Flight Manual.

FAA APPROVED: _____



William S. Whitton, Jr.
ODA Lead Administrator
ODA-511131-CE

DATE: _____



This page intentionally left blank.

GULFSTREAM AEROSPACE
GIV / G300 / G400 AIRPLANE FLIGHT MANUAL
SUPPLEMENT NO. GIV-2016-01

LOG OF REVISIONS

Revision Number	Affected Pages	Description of Revision

GULFSTREAM AEROSPACE
GIV / G300 / G400 AIRPLANE FLIGHT MANUAL
SUPPLEMENT NO. GIV-2016-01

This page intentionally left blank.

GULFSTREAM AEROSPACE
GIV / G300 / G400 AIRPLANE FLIGHT MANUAL
SUPPLEMENT NO. GIV-2016-01

SECTION 0 PREFACE

Introduction

This Airplane Flight Manual Supplement provides the limitations for Gulfstream GIV (GIV / G300 / G400) aircraft having sealant compound improperly applied to the APU enclosure.

SECTION 1 LIMITATIONS

Under **01-49-10: APU Operating Limits**, add the following at the bottom of the section.

APU Operation:

Ground:

Unattended ground operations of the APU are prohibited.

Flight:

Use of the APU during flight is prohibited except for the following conditions:

- Dual engine failure during flight
- Dual alternator / converter failure during flight
- Single engine failure during flight
- Single alternator / converter failure during flight

Dispatch is **not** permitted with any engine alternator and/or converter inoperative.

GULFSTREAM AEROSPACE
GIV / G300 / G400 AIRPLANE FLIGHT MANUAL
SUPPLEMENT NO. GIV-2016-01

SECTION 2 NORMAL PROCEDURES

No Change

SECTION 3 ABNORMAL PROCEDURES

No Change

SECTION 4 EMERGENCY PROCEDURES

No Change

SECTION 5 PERFORMANCE

No Change